

Club House Loft Assembly Instructions

Tools Needed

- Flat Screwdriver
- Phillips Screwdriver
- Tape measure
- Optional Power Drill with Phillips bit



Step 1:

Start installation a couple feet from the back wall. Slide the lower back rail to the right side panel. The metal brackets will lock into place. If you have trouble with the tabs not clearing the other bracket, use a flat screwdriver to gently pull back the tab of the bracket. Put set screws in each of the brackets using $\frac{3}{4}$ " silver screws.



Step 2

Repeat with the left side panel. Put set screws in each of the brackets using $\frac{3}{4}$ " silver screws.



Step 3

Add the front rail using the same method as the back rail. Put set screws in each of the brackets using $\frac{3}{4}$ " silver screws.



Step 4

Add the upper back rail with the house design (no windows).



Step 5

Add the upper front rail with the house design on it (with windows and door cutout).



Step 6

Add the curio lights to the bottom of the upper back board. Attach them with 3/4' silver screws. Plug them into the control box that has the lead leading to a screw between them. That screw will be the touch sensor for the operation of the lights.



Step 7

Add the light light to the upper back panels top. Put the cord through the hole and screw it on using two black screws provided. Plug it into the control box with the lead that leads to the back of one of the upper brackets. That upper bracket will be the control for the lights from the inside.



Step 7

Add corner trim. Each piece should be labeled with side it belongs. Screw on with 3 1 1/4" screw on each corner.



Step 8

Now with help pick up the unit and move to the back wall.

Step 9

Add slats to the top and bottom. Screw them in using 1 $\frac{1}{4}$ " black screws.



6.